



nextarTM



**Ma828 | Digital Mp3 Player
Instruction Manual**

Content

1. Operation.....	2
2. Turn the player ON/OFF.....	2
3. Select menu options.....	2
4. Music.....	2
5. Voice.....	3
6. Settings.....	3
Equalizer.....	4
Play mode.....	4
Contrast.....	5
Backlight.....	5
Power save (auto power off).....	6
Record set.....	6
Language.....	7
Exit.....	7
7. Delete single file.....	7
8. About memory size.....	8
9. Charging the battery.....	8
Lyrics.....	8
10. More information.....	9
Trouble shooting.....	9
Technical specification.....	10

Operation

Turn the player ON/OFF

Press **PLAY** button to turn the unit ON.

Press and hold **PLAY** button to turn the unit OFF.

Warning: Do not turn the unit OFF while you are downloading music to the device. Doing so can result in the loss of any unsaved data.

Select Menu Options

1. Press **PLAY** to turn the unit ON and enter music standby mode.
2. Press and hold **MODE** to enter main menu.
3. Press **PREV** or **NEXT** to navigate to the desired menu: *Music, Voice, Record, Settings, Delete, About* (Memory status) and *Exit*.
4. Press **MODE** again to confirm your selection.

Music

1. Press and hold **PLAY** to turn the unit ON and enter music standby mode.
2. Press **PLAY** to start playback of first music file, or press **NEXT** or **PREV** to scroll through the list of saved music files. The "►" icon appears on the left-hand side of the display.

Note: To momentarily pause playing, press the **PLAY** button. The "II" icon will appear on the display. Press **PLAY** again to resume normal playback.

3. Press **NEXT** once to skip forward to the next track or press it repeatedly to skip forward several tracks. Press **PREV** once to skip backward to the previous track or press it repeatedly to skip backward several tracks. Press and hold **PREV** or **NEXT** to search quickly within a track.
4. To adjust the volume level, press **VOLUME +/-** until the desired level is reached.
5. To stop music playback (while playing or paused), press **PLAY** for one second. Then press **PREV** or

NEXT to select a new track and then **PLAY** to begin playing the new song.

Voice

Recording

1. Press **MODE** for two seconds to enter main menu.
2. Press **PREV** or **NEXT** until display reads *Record*. Press **MODE** to confirm.
3. Press **PLAY** to start recording.
4. Press **PLAY** to pause recording.
5. Press **PLAY** again to resume recording.
6. Press **MODE** to stop voice recording during recording or pause.

Playing back recorded voice file

1. Press **MODE** for 2 seconds to enter main menu.
2. Press **PREV** or **NEXT** until display reads *Voice*.
3. Press **MODE** to confirm.

Press **PLAY** to start playing the first recorded voice file in the list, or press **PREV** or **NEXT** to scroll through the file list until you locate the recorded voice file you want to play back, and then press **PLAY** to begin playing that file.

Settings

1. Press **MODE** for two seconds to enter main menu.

2. Press **PREV** or **NEXT** until the screen reads **Settings**.
3. Press **MODE** to confirm.
4. Press **NEXT** or **PREV** to navigate to the various submenus (see below).
5. Press **MODE** to enter the desired submenu.

Equalizer

1. Once in the *Setting* mode, press **PREV** or **NEXT** until you reach *EQ*.
2. Press **MODE** to access *Equalizer* mode options.
3. Press **PREV** or **NEXT** to select an *Equalizer* mode: *Normal*, *Full Bass*, *Rock*, *Jazz*, *Classical*, or *Pop*.
4. Press **MODE** to confirm your selection.
6. Press **PREV** or **NEXT** to get to *Exit*.
7. Press **MODE** to return to the *Settings* selections.
6. Press **PREV** or **NEXT** to get to *Exit*. Press **MODE** to return to the *Playback* mode.

Play mode

1. Once in the *Setting* mode, press **PREV** or **NEXT** until you reach *Play*.
2. Press **MODE** to access *Play* mode options.
3. Press **PREV** or **NEXT** to select desired *Play Mode*: *Normal*, *Repeat one*, *Repeat all*, *Random*, *Shuffle all*, or *Intro*. (Note: When *Intro* mode is activated, the unit will play the first 10 seconds of each song).
4. Press **MODE** to confirm your selection.
5. Press **PREV** or **NEXT** to get to *Exit*.
6. Press **MODE** to return to the *Settings* selections.
7. Press **PREV** or **NEXT** to get to *Exit*.

8. Press **MODE** to return to the *Playback* mode.

Contrast

1. Once in the *Setting* mode, press **PREV** or **NEXT** until you reach the *Contrast* settings.
2. Press **MODE** to access *Contrast* options.
3. Press **PREV** or **NEXT** to adjust LCD contrast.
4. Press **MODE** to confirm your setting.
5. Press **PREV** or **NEXT** to get to *Exit*.
6. Press **MODE** to return to the *Settings* selections.
7. Press **PREV** or **NEXT** to get to *Exit*.
8. Press **MODE** to return to the *Playback* mode.

Backlight

1. Once in the *Setting* mode, press **PREV** or **NEXT** until you reach *B.L. Time*.
2. Press **MODE** to access *Backlight* options.
3. Press **PREV** or **NEXT** to select backlight time: 5 seconds, 10 seconds, 15 seconds, 20 seconds, 25 seconds, 30 seconds, 35 seconds, 40 seconds, 45 seconds, 50 seconds, 55 seconds, 60 seconds .
4. Press **MODE** to confirm your selection.
5. Press **PREV** or **NEXT** to get to *Exit*.
6. Press **MODE** to return to the *Settings* selections.
7. Press **PREV** or **NEXT** to get to *Exit*.
8. Press **MODE** to return to the *Playback* mode.

Power Save (auto power off)

1. Once in the *Setting* mode, press **PREV** or **NEXT** until you reach *Pwr Save*.
2. Press **MODE** to access *Power Save* options.
3. Press **PREV** or **NEXT** to select desired time of auto power-off: *disable*, *2 mins.*, *5 mins.*, or *10 mins.*
4. Press **MODE** to confirm your selection.
5. Press **PREV** or **NEXT** to get to *Exit*.
6. Press **MODE** to return to the *Settings* selections.
7. Press **PREV** or **NEXT** to get to *Exit*.
8. Press **MODE** to return to the *Playback* mode.

Record set

1. Once in the *Setting* mode, press **PREV** or **NEXT** until you reach *Record*.
2. Press **MODE** to access Recording options, and to set *Encoder* or *Sample Rate*.
3. Press **MODE** to confirm your selection.
 - 4a. In *Encoder*, press **PREV** or **NEXT** to select either *PCM*, *IMADPCM* or *MSADPCM*. **OR**
 - 4b. In *Sample Rate*, press **PREV** or **NEXT** to select your desired recording bit rate of *8000 Hz*, *11025 Hz*, *16000 Hz*, *22050 Hz*, or *32000 Hz*.
5. Press **MODE** to confirm your selection.
6. Press **PREV** or **NEXT** to get to *Exit*.
7. Press **MODE** to return to the *Settings* selections.
8. Press **PREV** or **NEXT** to get to *Exit*.
9. Press **MODE** to return to the *Playback* mode.

Language

1. Once in the *Setting* mode, press **PREV** or **NEXT** until you reach *Language*.
2. Press **MODE** to access display *Language* options.
3. Press **PREV** or **NEXT** to select to select your desired language – *English, Polish, German* or *Chinese*. 4. Press **MODE** to confirm.
5. Press **PREV** or **NEXT** to get to *Exit*.
6. Press **MODE** to return to the *Settings* selections.
7. Press **PREV** or **NEXT** to get to *Exit*.
8. Press **MODE** to return to the *Playback* mode.

Exit

Selecting *Exit* in any menu will return you to the Return to previous menu.

Delete single file

1. In *Play* mode, press **MODE** for two seconds to enter main menu.
2. Press **PREV** or **NEXT** until the screen reads *Delete*.
3. Press **MODE** to enter *Delete* mode.
4. Press **PREV** or **NEXT** to select whether you want to delete a music or voice file.
5. Press **MODE** to confirm your choice.

6. Screen will read *Are you sure you want to delete the file?* Press **NEXT** to advance to the next screen. This will display the song title.
 7. Press **PREV** or **NEXT** to advance to the next screen. Then press **PREV** or **NEXT** to select Yes or No.
 8. Press **MODE** to confirm your selection.
 9. Press **PREV** or **NEXT** to select the music file you want to delete.
 10. Once you have deleted the desired file(s), press **MODE** for 2 seconds to return to the Play mode.
- Note:** "Read-only" music files cannot be deleted.

About memory size

1. Press **MODE** for two seconds to enter main menu.
2. Press **PREV** or **NEXT** until you reach *About*.
3. Press **MODE** to access the device's memory information.
4. Press **PREV** or **NEXT** to check the total memory of the player (*INT*) and the remaining available memory (*FREE*) capacity.

Charging the Battery

Plug the rounded end of the included cable into the device's headphone jack.
Plug the USB connector (flat square end) into the USB port of any computer.

Lyrics

This player supports the Lyrics function of MP3 playback.

Note:

1. The lyric file format should be in the **.LRC** format.
2. The lyric file name should be same as the song's name.

For example:

Song name: **Jay-Sky.mp3**

Lyric file name: **Jay-Sky.lrc**

3. The lyric file should be saved in the same folder as the song.

More Information

Trouble Shooting

Symptom	Cause	Solutions
Press PLAY but no display.	1. Battery is out of power.	1. Charge the battery.
No sound.	1. Low volume or no music files stored on the device. 2. Battery is out of power. 3. MP3/WMA/WAV music file is damaged.	1. Adjust the volume. 2. Charge the battery. 3. Replace damaged music files.

Cannot play MP3/WMA file created by user	Files that do not play may be damaged (see above), or might be in a non-standard format. This player can only support standard compressed format. Please don't download non-standard MP3 music especially Layer-1 or Layer -2 files.	Re-download or create a standard MP3/WMA file version of the file.
--	--	--

Technical Specification

Bit rate: 8~320 Kbps

SN R: >80(1KHz)

Output power:<5 Mw *2

USB port: USB 2.0 High speed

ID3 Tag display with Lyrics, blue backlight

Memory size: 64MB - 2GB

MP3 / WMA

Operation conditions: humidity <85%, -10℃ ~ 40℃

Compatible with Windows ME, 2000 and XP Operating Systems (no driver required).